

# 2008 FIT - Air Mix Control Cable Adjustment

1. From under the dash, open the clamp (A), then disconnect the air mix control cable (B) from the air mix control linkage (C).
2. Set the temperature control dial to Max Cool.
3. Turn the air mix control linkage fully counterclockwise as shown above, and hold it. Attach the air mix control cable to the air mix control linkage, then install the air mix control cable housing into the clamp.

