



Tools used:

- 1- Phillips screw driver
- 1- Flat head screw driver
- 1-8mm nut driver
- 1- 10mm socket
- 1- Ratchet
- 1- Pliers

I Trice piece edia dii imake	1
1- 2.75" Injen filter	(#1013)
1- Two bend silicone wrap hose	(#3046)
1 2.50" straight hose	(#3048)
4- power-bands(.040) (.312)	(#4003)
1- 1525 sensor grommet	(#6014)
1- 3" 8mm vacuum hose	(#3091)
1- m6 vibra-mount	(#6020)
1- m6 flange nut	(#6002)
1- Fender washer	(#6010)
1- 5 page Instruction	

Note: Hydro-shields, filter charger kits and replacement filter are sold on-line at:

"injenonline.com"

Hydro-shield sold for this application is X-1033

Congratulations! You have just purchased the best engineered, dyno-proven cold air intake system available.

Please check the contents of this box immediately.

Report any defective or missing parts to the Authorized Injen Technology dealer you purchased this product from.

Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the dealer you purchased this product from.

Installation DOES require some mechanical skills. A qualified mechanic is always recommended.

*Do not attempt to install the intake system while the engine is hot. The installation may require removal of radiator fluid line that may be hot.

Injen Technology offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.

Injen Technology 244 Pioneer Place Pomona, CA 91768 USA

Please check the contents of this box immediately. Note: This intake system was Dyno-tested with an Injen filter and Injen parts. The use of any other filter or part will void the warranty and CARB exemption number.

Parts and accessories are available on line at "Injenonline.com"

Note: The installation of this cold air intake does require mechanical skills. Removal of the front bumper requires loosening and removing several plastic plugs and screws that may be difficult. In addition to removing the bumper, you will also have to remove the air resonator box, battery and tray when beginning this installation. Injen strongly recommends that this system be installed by a professional mechanic.

MR Technology, "The World's First Tuned Intake System!" Optimum performance, Factory safe air/fuel ratio.





Hydro-shield X-1033

