

# Component Location Index

**PADDLE SHIFTER —  
(DOWNSHIFT SWITCH)  
(Five-position transmission)**

**PADDLE SHIFTER +  
(UPSHIFT SWITCH)  
(Five-position transmission)**

**POWERTRAIN CONTROL  
MODULE (PCM)**

**PARK PIN SWITCH**

**SHIFT LOCK SOLENOID**

**DATA LINK  
CONNECTOR (DLC)**

**NOTE: The illustration shows the five-position transmission; the seven-position transmission does not have the paddle shifters.**

**OUTPUT SHAFT  
(COUNTERSHAFT)  
SPEED SENSOR**  
Replacement,  
page 14-223

**A/T CLUTCH PRESSURE  
CONTROL SOLENOID VALVE A**  
Test, page 14-214  
Replacement, page 14-216

**A/T CLUTCH PRESSURE CONTROL  
SOLENOID VALVE C**  
Test, page 14-219  
Replacement, page 14-221

**INPUT SHAFT (MAINSHAFT)  
SPEED SENSOR**  
Replacement, page 14-222

**2ND CLUTCH TRANSMISSION  
FLUID PRESSURE SWITCH**  
Replacement, page 14-224

**A/T CLUTCH PRESSURE CONTROL  
SOLENOID VALVE B**  
Test, page 14-217  
Replacement, page 14-221

**TRANSMISSION  
RANGE SWITCH**

**3RD CLUTCH TRANSMISSION  
FLUID PRESSURE SWITCH**  
Replacement, page 14-225

**SHIFT SOLENOID  
HARNESS CONNECTOR**  
Replacement, page 14-212

**SHIFT SOLENOID VALVE D**  
Test, page 14-209  
Replacement, page 14-212

**SHIFT SOLENOID VALVE C**  
Test, page 14-209  
Replacement, page 14-212

**ATF TEMPERATURE  
SENSOR**  
Test/Replacement,  
page 14-226

**SHIFT SOLENOID VALVE B**  
Test, page 14-209  
Replacement, page 14-212

**SHIFT SOLENOID VALVE A**  
Test, page 14-209  
Replacement, page 14-212

