

Front Stabilizer Bar Removal and Installation

(//app.na.readspeaker.com/cgi-bin/read?customerid=7827&lang=en_us&readid=dvRSContent&

url=www.chiltonlibrary.com%2fRepair%2fReadArticleContent%2fmwellPhwg8CDi3HbJml1QS8hQKulirFtsrGk84hxp9-FAeV81%7c153825%7c36548)

NOTE


Applicable vehicles:

- 2015-16 Honda FIT

Front Stabilizer Bar Removal and Installation

Removal


1. Vehicle - Lift
2. Front Wheels - Remove
3. Engine Undercover - Remove
4. Stabilizer Link - Disconnect
 1. Disconnect both sides of the stabilizer link from the stabilizer bar.
5. Stabilizer Bar - Remove



1. Remove the bushing holders (A).
2. Remove the bushings (B).
3. Move the stabilizer bar (C) toward the driver's side, and remove the stabilizer bar.

Installation

1. Stabilizer Bar - Install



1. Install the stabilizer bar (A) from the driver's side.
2. Install the bushings (B) on the stabilizer bar.

NOTE:

- Note the direction of installation for the bushing.
- Align the paint marks (C) on the stabilizer bar with the side of the bushings.

3. Install the bushing holders (D).

2. Stabilizer Link - Connect

1. Connect both sides of the stabilizer link from the stabilizer bar.

3. Engine Undercover - Install

4. Front Wheels - Install

Copyright ©2018 by Chilton, an imprint of Cengage Learning

(/lh/Home/Index/mwellPhwg8CDi3HbJml1QSBhQKk8NHkn5mvP8IZJ3iRog0Tk1)Home [Terms and Conditions \(http://www.cengage.com/content/footer/terms_of_use.aspx\)](http://www.cengage.com/content/footer/terms_of_use.aspx)

[Privacy Statement \(http://www.cengage.com/content/footer/privacy_statement.aspx\)](http://www.cengage.com/content/footer/privacy_statement.aspx) [Contact Us \(http://www.cengage.com/contact/\)](http://www.cengage.com/contact/)

